


EN USER GUIDE


MICROWAVE COMBI OVEN

De Dietrich 




2


A




B



C




D



•1






E



•2






A







B

2^s




C




•2




D



E






F



•3




A







B




C



D




E







F



G



H



EN

DEAR CUSTOMER,

Discovering a De Dietrich product means experiencing the range of unique emotions.

The attraction is immediate, from the moment you set eyes on the product.

The sheer quality of the design

shines through, thanks to the timeless style and outstanding finishes which make each component an elegant and refined masterpiece in its own right, each one

in perfect harmony with the others. Next, comes the irresistible urge to touch it.

De Dietrich design makes extensive use of robust and prestigious materials, where the accent is placed firmly upon authenticity. By combining state-of-the-art technology

with top quality materials, De Dietrich produces

beautifully crafted products to help you get the most from the culinary arts, a passion

shared by all lovers of cooking and fine food. We hope that you enjoy using this new appliance.

Thank you for choosing a De Dietrich product.

De Dietrich 

CONTENTS

1 / DESCRIPTION OF THE OVEN

- Presentation of your oven2
- Description of controls9
- Description of accessories10

2 / SETTING

- Setting the clock11
- Changing the clock11
- Minute Minder11
- Locking the controls11
- Settings menu11
- Controlling the turntable11

3 / USE

- Cooking modes12
- Immediate cooking14
 - Changing the temperature14
 - Changing the power14
 - Programming the time14
 - Delayed start time14
- Automatic cooking functions14
- Automatic defrosting functions15
- Memorise a cooking mode15

4 / CARE

- External surface15
- Changing the lamp15

5 / ANOMALIES AND SOLUTIONS16

6 / AFTER-SALES SERVICE16


7 / FUNCTION SUITABILITY TESTS17

1 DESCRIPTION OF THE OVEN



1 CONTROL PANEL

• THE DISPLAY




- 1- Cooking modes display
- 2- Oven temperature and clock display
- 3- End of cooking time indicator
- 4- Cooking time indicator
- 5- Stopping the turntable
- 6- Power/weight indicator
- 7- Shelf runner indicator

- Control locking indicator
- "Recipes" function indicator
- Cooking time indicator
- Minute minder indicator
- Cooking end indicator

Note:
By default, after the time is displayed the display switches off after a few minutes if the user does not do anything. This function may be modified with the "time display" function in the settings menu.

• BUTTONS



- 1 On/Off
- 2 Adjusting the temperature and power
- 3 Adjusting the clock, the time and the end of cooking, the minute minder
- 4 Access the settings MENU

• CONTROL KNOB

This is a rotating knob with central button to choose programmes, increase or reduce values and confirm.

The drawings on the control knob are symbolised as follows:



TURN the knob.



PRESS the centre of the knob to confirm.

• 1 DESCRIPTION OF THE OVEN



2 ACCESSORIES

Anti-tip safety rack (fig. A).

This allows you to toast, brown or grill. The rack should never be used with other metal cookware on the microwave, grill + microwave or forced air + microwave modes. However, you can reheat food in an aluminium tray providing this is isolated from the rack using a plate.

The glass drip tray (fig. B).

This can be used half-filled with water for double-boiler cooking methods in fan cooking. It can be used as a cooking dish.



Note:

Take care to place the drip tray in the centre of the side racks to avoid affecting air circulation.

Rack + glass drip tray (fig.C)

to roast and retain the cooking juices, place the rack on the drip tray.

The shelf supports (fig.D)

2 hanging supports allow you to use the rack at three heights.

The turntable (fig.E)

The turntable ensures equal cooking of food throughout with no need to intervene. It rotates in both directions. If it does not turn, verify that all components are properly positioned.

It may be used as a cooking dish. For easy removal, wells are provided on either side.

Rotation is controlled by the drive shaft and the wheel support.

If you take out the support with the drive

spindle, make sure you do not let water get into the motor spindle orifice.

Remember to put back the support, the support wheels and the glass turntable.

Do not try to rotate the glass turntable manually, as you could damage the drive system. If it does not turn smoothly, make sure that there is nothing in the well beneath the turntable.

When the turntable is in the stop position, large dishes can be used which cover the entire surface of the oven. In this case, it is necessary to turn the container or to mix its content half-way through the programme.

OPERATING PRINCIPLE

The microwaves used for cooking are electromagnetic waves. They are commonly found in our environment in the form of radio waves, light and infrared rays.

Their frequency is in the 2450 MHz range. Their behaviour:

- They are reflected by metals.
- They travel through all other materials.
- They are absorbed by water, fat and

sugar molecules.

When food is exposed to microwaves its molecules begin moving rapidly, causing it to heat up. The penetration depth of waves into the food is approximately 2.5 cm; if the food is thicker, the centre of the food will be cooked by conduction, as in conventional cooking.

Note that microwaves cause a simple thermal phenomenon within food and are not harmful to health.

• 2 SETTINGS



SETTING THE CLOCK (fig. A)

When switching on, the display flashes at 12:00.

Adjust the time by turning the dial then press \rightarrow to validate.

If there is a power cut, the clock flashes.

CHANGING THE CLOCK (fig. B)

Press the \odot button for a few seconds until the clock flashes. Adjust the clock by turning the knob and then press \rightarrow to confirm.

MINUTE MINDER (fig. C)

This function can only be used when the oven is off.

Press \odot . 00:00 flashes. Set the minute minder by turning the knob and then press \rightarrow to confirm. The timer starts.

Once the time has lapsed, there is a sound signal. To stop it, press any key.

NB: You can modify or cancel the timer at any time.

To cancel, return to the timer's menu and set to 00:00.

CONTROL LOCKING

Child safety (fig. D)

Press \updownarrow and \odot at the same time until the symbol \square appears on the screen. Control locking is accessible during cooking or when the oven has stopped.

N.B.: only the \odot button remains active during cooking.

To unlock the keypad, press \updownarrow and \odot together until the \square symbol disappears off the screen.

SETTINGS MENU (fig. E)

You can adjust different settings on your oven:

contrast, sounds and demo mode.

To do this, press \equiv for a few seconds to access the settings menu.

See the table below:

Default settings	
	Sounds - beeps: Position ON, sounds active. Position OFF, no sounds.
	Contrast: The brightness of the display is adjustable from 10 to 100%.
	DEMO mode: Switch on / off the "DEMO" mode; demonstration mode used for show. Switch it off to make your oven work.
	Time display: ON position by default: SLEEP is displayed and the display switches off after a few minutes. OFF position: the display remains on.

To modify the different settings if necessary, turn the control knob and then press \rightarrow to confirm.

To come out of the settings menu at any time, press \odot .

CONTROLLING THE TURNTABLE (fig.F)

If you think that there is not enough space for it to rotate freely in the oven, you can stop the turntable before or during the programme.

- Press the \odot and \equiv buttons at the same time for a few seconds.

The --- symbol appears in the display.

• Restarting the turntable

Press and hold the \odot and \equiv buttons simultaneously for a few seconds until the symbol --- appears in the display.

• 3 USE



COOKING

This oven allows you to access 4 different types of cooking mode:

- The Microwave function
- The combined microwave functions (microwave + Traditional cooking).
- The traditional cooking functions.
- The Automatic cooking functions.

MICROWAVE FUNCTIONS

Position	Power	Use
 Microwave	1000W	Quick reheating drinks, water and dishes that contain a large quantity of liquid. Cooking food that contains a lot of water (soups, sauces, tomatoes, etc.).
 Microwave	800W / 900W	Cooking fresh or frozen vegetables.
 Microwave	600W	Melting chocolate.
 Microwave	500W	Cooking fish and seafood. Heating on 2 levels. Cooking dry vegetables over a low heat. Reheating or cooking fragile egg-based foods.
 Microwave	400W / 300W	Cooking dairy products and jam at low heat.
 Microwave	200W	Manual defrost. Softening butter and ice cream.
 Microwave	100W	Defrosting pastries that contain cream.
 Defrosting	200W	

• 3 USE



COMBINED MICROWAVE FUNCTIONS

Position	Recommended T°C and power mini - maxi	Use
 Fan cooking + microwave	200°C 50°C - 200°C 300W 100W - 300W	This function combines microwave cooking with fan cooking to save you a considerable amount of time. Recommended for meat, chicken and roasts placed in a dish.
 Medium grill + microwave	2 1-4 500W 100W - 700W	This function lets you use the grill and the microwave simultaneously, which makes cooking very quick. This function lets you cook and brown foods such as gratin dishes and meats. It can be used before or after cooking, depending on the recipe.
 Full grill + microwave	4 1-4 500W 100W - 700W	Cooking in full grill + microwave to grill meat and fish.

TRADITIONAL COOKING FUNCTIONS

Position	T°C recommended mini - maxi	Use
 Full grill	2 1 - 4	Recommended for grilling cutlets, sausages, toasting bread and prawns placed on the grill.
 Pulsed full grill	200°C 50°C - 200°C	Roasts and poultry are juicy and crisp all over. To retain the moist texture of fish steaks.
 Fan cooking*	200°C 50°C - 220°C	Recommended for keeping white meat, fish and vegetables moist.



IMMEDIATE COOKING (fig.A)

The programmer must only display the time. It should not be flashing.

Turn the control knob until you get to the cooking function of your choose, then confirm.

MODIFY THE TEMPERATURE (fig.B)

- Press the \downarrow^w key, the Temperature flashes, you may adjust it.

Adjust the temperature by turning the knob and then press to confirm.

- Example: 180°C.

MODIFY THE POWER (fig.C)

- Press the \downarrow^w key, the power (300W) flashes, you may adjust it.

- Set the power, using the knob.

- Example: 200 Watts.

Confirm by pressing the knob.

PROGRAMMING THE COOKING TIME (fig. D)

Use the immediate cooking programme, then press \odot ; the cooking time \odot flashes and it is now possible to set it.

Turn the knob to adjust the cooking time. Press to confirm.

Your oven has the "SMART ASSIST" function which, when programming a cooking time, will suggest a cooking time which can be modified depending on the selected cooking mode.

The cooking time is saved automatically after a few seconds.

NB: Halfway through the cooking time, the oven beeps and displays «TURN» to tell you to turn your food over.

DELAYED START (fig. E)

Proceed as for programmed cooking.

After setting the cooking time, press \odot .

The display flashes. Set the cooking end time by turning the knob. The cooking end time is automatically saved after a few seconds. The cooking end time display stops flashing.

THE AUTOMATIC COOKING FUNCTIONS (fig. F)

Programming automatic cooking by weight or time selects the cooking settings for you. The programmer must only display the time. It should not be flashing.

Select Auto mode using the knob. The logo flashes.

- Select an AUTOMATIC cooking mode (See table)

- A suggested weight flashes on the screen.

- Example: P3 \rightarrow weight, 500G.

-Adjust the weight or time using the knob. Example: 650g.

Food	14 Recipes
Fibrous fresh vegetables	P01
Fresh vegetables	P02
Frozen vegetables	P03
Poultry (combined function)	P04
Beef (combined function)	P05
Fish	P06
Fresh pizza (combined function)	P07
Frozen pizza (combined function)	P08
Frozen pizza (Traditional cooking)	P09
Prepared fresh meal (Microwave)	P10
Prepared frozen meal	P11
Prepared fresh meal (combined function)	P12
Savoury tart	P13
Potato gratin quiche	P14

• 3 USE



- Confirm by pressing the knob once.
- The icon of the cooking mode used and the time calculated automatically are displayed. The oven starts.

THE AUTOMATIC DEFROSTING FUNCTIONS

This oven allows you to access 3 different types of programmes in the defrost mode

- Automatic defrost P1, P2 or P3.

You simply select the type of programme and enter the weight.

P1: The automatic defrost mode for meat, poultry and ready-made meals.

P2: The automatic defrost mode for fish.

P3: The automatic defrost mode for bread and pastries.

NB: A delayed start cannot be programmed for defrost functions.

MEMORISE A COOKING MODE

You can memorise 3 cooking programmes of your choice that may be used later.

- Programme a memory (fig. G) :

Select a cooking mode, its power or its temperature and then press the knob until you get to «MEM 1». Choose one of the 3 memories by turning the control knob and confirm to memorise it. Confirm again to start cooking.

NB: If the 3 memories are saved, any new memorisation will replace the previous one.

A delayed start cannot be programmed for memorisations.

- Select one of the 3 memories already saved (fig.H) :

Turn the knob and go to MEMO, then confirm. Scroll through the memories with the knob and confirm the one you want. Cooking starts.



Note:

To stop the oven at any time, hold down the ① key.

To pause the cooking in progress, press the knob.

• 4 CARE



EXTERNAL SURFACE

Use a window washing product applied to a soft cloth. Do not use abrasive creams or scouring sponges.



Warning
Do not use scouring products, abrasive sponges or metal scrapers to clean the glass oven door as this could scratch the surface and cause the glass to shatter.

REPLACING THE LAMP

For all operations on the lamp, contact the After Sales Department or a qualified professional accredited to work on the brand.

• 5 ANOMALIES AND SOLUTIONS



You may resolve certain little problems yourself:

The oven is not heating. Check that the oven is correctly connected and that your installation's fuse is not out of service. Increase the selected temperature. Check that the oven is not set to **DEMO** mode.

The oven light is not working. Replace the bulb or the fuse. Check that the oven is correctly connected.

The cooling fan continues to operate after the oven stops. This is normal; the fan may continue running until a maximum of 1 hour after cooking to lower the temperature inside and outside the oven.

• 6 AFTER-SALES SERVICE




SERVICING AND REPAIRS

Any repairs to your appliance must be made by a qualified professional accredited to work on the brand. When calling, please provide the full references of your appliance (commercial reference, service reference, serial number), so that we can handle your call better. This information appears on the manufacturer's nameplate on the equipment.

GENUINE PARTS

When having work carried out, insist on the use of genuine, certified spare parts **only**.



xxxx MHz	B XXXXXXXX	
xxxx W	C XXXXXXXX	
xxx-xxxV ~ xxHz	H N: XX-XX-XXXXX	
Service conso.		Made in France

B: Commercial reference

C: Service reference

H: Serial number

• 7 FUNCTION SUITABILITY TESTS

Functional suitability tests in accordance with IEC/EN/NF EN 60705 standards.

The International Electrotechnical Commission, SC.59K, has established a standard for comparative performance tests conducted on various micro-wave ovens. We recommend the following for this appliance:

Test	Load	Approx. time	Power level selector	Cookware/Tips
Custard (12.3.1)	1000 g	16-18 min	500 W	Pyrex 227 On the turntable
Savoie cake (12.3.2)	475 g	6-7 min	700 W	Pyrex 827 On the turntable
Meatloaf (12.3.3)	900 g	14 min	700 W	Pyrex 838 Cover with plastic film. On the turntable
Defrosting meat (13.3)	500 g	11-12 min	200 W	On a flat plate On the turntable
Defrosting raspberries (B.2.1)	250 g	6-7 min	200W	On a flat plate On the turntable
Potato gratin (12.3.4)	1100 g	23-25 min	Low grill + 700 W	Pyrex 827 On the turntable
Chicken (12.3.6)	1200 g	24-26 min	Full grill + 500 W	Place on the grill assembly + drip tray Insert the dish at level 1 from the bottom Turn midway through
		35-40 min	Fan cooking 200°C + 200 W	In an enamelled earthenware dish Place on the rack at level 1 from the bottom
Cake (12.3.5)	700 g	20 min	Fan cooking 220°C + 200 W	Pyrex 828 Place on the rack at level 1